


ELECTRICAL WIRING DIAGRAM

NEXIA
CIELO
RACER II



DAEWOO MOTOR CO., LTD.

ELECTRICAL WIRING DIAGRAM

NEXIA ■

CIELO ■

RACER II ■



DAEWOO MOTOR CO., LTD

CONTENTS

A. GENERAL DESCRIPTION

1. How to read wiring diagram
2. Circuit identification code
3. Wiring color
4. ECM classification

B. HARNESS CONNECTORS AND FUSE, RELAYS

1. Harness connector and ground location
2. Fuse and relay location

C. ELECTRICAL WIRING DIAGRAMS

FOREWORD

All information illustrations and specifications contained in this manual are based on the latest product information available at the time of manual approval.
The right is reserved to make changes at any time without notice.




A. GENERAL DESCRIPTION

1. HOW TO READ WIRING DIAGRAM

- Ex) E1: Head Lamp(Left)
 E2: Head Lamp(Right)
 K7: Head Lamp Relay

"30" Line: Battery Positive(+) Line
 "15" Line: Ignition ON
 "15A" Line: Ignition ON
 (But, when cranking engine(Ignition III position), power is not supplied.)
 "58" Line: Light Switch ON



A. 123: A number(123) indicates the location of connecting wiring in this diagram.
 F5: Component connected with this wiring

B. Components and Terminal Number.
 K7: Head lamp Relay
 86, 30, 85, 87: Terminal Number

C. Connector No. and Terminal No. of the two connecting harness.
 - Terminal of X 50 Connector

D. Cable Color and Wiring Sectional Area
 First Letter: Basic Color
 Second Letter: Identification Color
 Figure: Cross Sectional Area

E. Ground Location

"B — A": A and B lines are connected.

"B — A": A and B lines are not connected, but different lines.

2. CIRCUIT IDENTIFICATION CODE

IDENTIFICATION	COMPONENT	PART NAME(EXAMPLE)
E	Lamp	Head Lamp, Fog Lamp
F	Protector	Fuse
G	Power Supply	Alternator, Battery
H	Transfer	Horn, Speaker, Turn Signal Lamp
K	Relay	Relay
L	Sensor	Ignition Coil
M	Motor	Wiper Motor, Window Motor
D	Meter	Tachometer, Volt Meter
R	Resistor	Blower Resistor
S	Switch	Wiper Switch: Defroster Switch
X	Connector	Connectors Between Harnesses
Y	Electrical	Driving Unit Solenoid Valve


3. WIRING COLOR

As the wiring harness includes a large number of cables to complete individual circuits, the insulator of each cable is color coded to prevent wrong wiring. The alphabetical symbols in the following table represent the color of cables and the same symbols are also used the wiring. The cable identification symbol consists of a figure and letters.

Symbol	Color	Symbol	Color
L	blue	Br	brown
Y	yellow	Gr	grey
G	green	R	red
W	white	B	black
VIO	violet		

The figure indicates the size of wire and the first and second letters denote the basic color and identification color, respectively.

The size of wire is indicated in terms of sectional area.




3. ECM CLASSIFICATION

- ECM Part Number

ENGINE	EMIS-SION	T/M	E C M			LOOP	IMMO.	AREA	
			TYPE	PART/NO.	I. D				
1.5 TBI	Leaded	M/T	EFI-4	16198389	ER	OPEN		Intense cold area	
				16186399	EN			High altitude area	
				16191059	EQ			General area	
	Unleaded	A/T	EFI-4	16191419	ED	OPEN			
				16186389	EB			High altitude area	
				16194919	RC			Hong kong, Singapore	
	Unleaded	M/T	IEFI-S	16199339	UD	CLOSE		Chile	
				16201659	TF			Guatemala	
				16186529	EC			General area	
1.5 MPI	Leaded	M/T	IEFI-6	16209699	SX	OPEN		High altitude area	
				16209689	SW			Intense heat/cold area	
				16207709	ES			General area	
		A/T	IEFI-S	16211909	PQ	CLOSE		High altitude area	
				16211899	PR			Intense cold area	
	Unleaded	M/T	IEFI-6	16207719	ET	OPEN		General area	
				16214669	PJ			Intense heat/cold area	
				16211879	PT		CLOSE	Chile	
				16217289	SC			Guatemala	
			IEFI-S	16221479	FC			General area, Australia	
				16236659	CK			ISRAEL	
		IEFI-6	16207729	EU	OPEN		O	NON IMMO.	
			IEFI-6	16212869	SS			Western Europe IMMO.	
		A/T	IEFI-6	16214689	RL	CLOSE		Western Europe non IMMO.	
				16211889	PU			Chile	
				16205729	EL			General area, Australia	
			IEFI-6	16236669	CL			ISRAEL	
				16214659	NA	CLOSE	O	Europe IMMO.	
				16207739	EV			General area, Western Europe Non immo., Australia	
1.5 DOHC	Leaded	M/T	IEFI-6	16219829	GQ	CLOSE		ISRAEL	
				16219329	NK	CLOSE		Intense heat/cold area	
	Unleaded	M/T	IEFI-6	16217229	HD	CLOSE	O	Europe IMMO.(Only France)	
				16219819	GP			High altitude area	
				16217239	HE			General area, Chile, Australia, Europe non immo.	
				16235989	SE			ISRAEL	
		A/T	IEFI-6	16217249	HG	CLOSE	O	Europe IMMO.	
				16214589	PF	CLOSE		General area, Chile, Israel, Australia	
		A/T	IEFI-S	16214639	NB	CLOSE		Europe IMMO.	
				16207779	EX			General area, Chile, Australia, Europe non immo.	
			IEFI-6	16235999	SF			ISRAEL	


- ECM Identification Method



You can not exchange IEFI-S ECM, and IEFI-6 ECM each other because those are different.

B. HARNESS CONNECTORS AND FUSE, RELAYS

1. HARNESS CONNECTORS AND GROUND LOCATION



1-1. CONNECTOR DESCRIPTION

- X2 Connector for IP and Front Harness(14 pin)
- X2A Connector for IP and Front Harness(8 pin)
- X3 Connector for IP and Engine Harness(14 pin)
- X3A Connector for IP and Engine Harness(4 pin)
- X4 Connector for IP and FI Harness(14 pin)
- X4A Connector for IP and FI Harness(8 pin)
- X4B Connector for IP and FI Harness(2 pin)
- X41 Connector for FI and TCM Extension Harness(20 pin)
- X42 Connector for FI and TCM Extension Harness(14 pin)
- X43 Connector for FI and TCM Body Harness(20 pin)
- X5 Connector for IP and Floor Harness(20 pin)
- X5A Connector for IP and Floor Harness(10 pin)
- X61 Connector for Floor and Front-Left Door Harness(14 pin)
- X62 Connector for Floor and Front-Right Door Harness(14 pin)
- X63 Connector for Floor and Rear-Left Door Harness(7 pin)
- X64 Connector for Floor and Rear-Right Door Harness(7 pin)
- X7 Connector for IP and ABS Harness(6 pin)
- X8 Connector for Floor and Rear Body Harness(14 pin)
- X81 Connector for Rear Body and Rear-End Harness(2 pin)
- X82 Connector for Rear Body and Tail Gate Harness(2 pin) - 3 Door, 5 Door Vehicle
- X9 Connector for FI and DOHC Injector Harness(2 pin) - DOHC Vehicle
- X11A Connector for IP Harness and Instrument Panel(16 pin)
- X11B Connector for IP Harness and Instrument Panel(12 pin)
- X11C Connector for IP Harness and Instrument Panel(6 pin) - Auto T/M 4-SP Vehicle
- X12 Connector for IP Harness and Center Console Harness(5 pin)
- X13 Connector for IP harness and Air Bag Harness(4 pin)
- X14 Connector for IP and Car Audio(13 pin)

* Abbreviation


IP: Instrument Panel

FI: Fuel Injection

1-2. GROUND LOCATION

- 1: Located at the center of steering column
- 2: Located at the side of battery
- 4: Located on the head side of engine cylinder
- 5: Located in the trunk room
- 6: Located under the drivers seat
- B: Body ground(part body is directly grounded to the vehicle body)

2. FUSE AND RELAY LOCATION



2) Fuse usage













Fuse No.	Capacity (A)	Usage	Fuse No.	Capacity (A)	Usage
1	10	ECM, TCM	12	30	Radiator temperature switch, A/C control switch
2	10	Parking lamp	13	20	Digital clock, reverse lamp, warning buzzer, rear window defroster switch, alternator "F", IP, cigarette lighter, glove box lamp
3	10	Air bag	14	30	Horn, electric fan relay
4	20	Head lamp high beam	15	20	Digital clock, hazard lamp switch, room lamp, trunk room lamp, warning buzzer, auto antenna
5	10	Head lamp low beam(left), HLLD motor(left)	16	30	Power window
6	10	Head lamp low beam(right), HLLD unit, HLLD motor(right)	17	10	Cassette
7	30	Injector, TCM, Immobilizer	18	30	Auto trunk switch, rear window defroster
8	20	Brake s/w, fuel pump relay, hazard lamp switch, ABS	19	30	time relay, central door locking relay, cassette
9	30	Wiper relay	20	30	Blower motor relay
10	10	Fuel inlet solenoid switch, ABS, immobilizer			Front fog
11	10	A/C compressor relay			

C. ELECTRICAL WIRING DIAGRAMS







C-1 Harness Connector Faces


C-2 Electrical Wiring Diagram

1) Ignition Switch, Starter Motor, Alternator, Wiring	14
2) Ignition Wiring (IEFI-6)	16
3) Injection Nozzle, ECM Power, ECM Ground "Wiring(IEFI-6)	18
4) Coolant Temperature Sensor(CTS), Manifold Air Pressure(Map) Sensor, Vehicle Speed Sensor, Throttle Position Sensor(TPS) IAC Valve, O ₂ Sensor wiring(IEFI-6)	20
5) "Service Engine Soon" Light, TCC, Fuel Pump, ALDL Tester Wiring(IEFI-6)	22
6) Ignition Wiring(IEFI-S)	24
7) Injection Nozzle, ECM Power, ECM Ground Wiring(IEFI-S)	26
8) Coolant Temperature Sensor(CTS), Manifold Air Pressure(MAP) Sensor, Vehicle Speed Sensor, Throttle Position Sensor(TPS) IAC Valve, O ₂ Sensor wiring(IEFI-S)	28
9) "Service Engine Soon" Light, TCC, Fuel Pump, ALDL Tester Wiring(IEFI-S)	30
10) Light Wiring	32
11) Front Fog Lamp & Rear Fog Lamp	34
12) Day Time Running Light, Clearance Lamp, Licence Plate Lamp, Horn Wiring	36
13) Glove Box Lamp, Cigarette Lighter, Digital Clock Room Lamp, Trunk Room Lamp, Wiring	38
14) Brake Lamp, Reverse Lamp, TCC Wiring	40
15) Turn Signal Lamp, hazard Lamp Wiring	42
16) Warning Buzzer, Auto Trunk, Fuel Inlet Switch Wiring	44
17) Rear Window Defroster Wiring	46
18) Wiper Wiring	48
19) Cassette Radio Wiring	50
20) Power Window Wiring(LHD, RHD)	52
21) Central Door Locking System Wiring(LHD, RHD)	54
22) I-P Wiring	57
23) ABS (Option)	60
24) TCM(Option)	61
25) Immobilizer, Air Bag(Option)	62
26) Air-Conditioning Wiring, Electric Fan, Blower Motor Wiring(IEFI-6 type)	63
26-1) Air-Conditioning Wiring, Electric Fan, Blower Motor Wiring(IEFI-S type)	67
27) Head Lamp Leveling Device(Option)	69

C-1. HARNESS CONNECTOR FACES

I-P CONNECTOR







C-2. ELECTRICAL WIRING DIAGRAM

1) IGNITION SWITCH, STARTER MOTOR, ALTERNATOR WIRING


- G1 BATTERY
- M1 STARTER MOTOR
- S1 IGNITION SWITCH
- S2 P/N SWITCH
- G2 ALTERNATOR




IGNITION SWITCH





IGNITION SWITCH





P/N SWITCH CONNECTOR

X2, X3 CONNECTOR
(I.P. WIRING HARNESS REFERENCE)




MANUAL TRANSMISSION VEHICLE





2) IGNITION WIRING(IEFI-6)





K1 ECM
 L1 IGNITION COIL
 Y1 IGNITION MODULE
 Y2 DISTRIBUTOR



- L1 Ignition Coil
 - Insulation Resistance: ∞
 - 1st Resistance: 0.35-0.45ohms
 - 2nd Resistance: 7.5-9.5kilo-ohms
- Y1 Ignition Module
 - Pick up Coil
 - Insulation Resistance: ∞
 - Coil Resistance: 500-1500ohms
 - Ignition System Check

Measuring terminal	Cranking	Starting
Ground - Distributor A	0V	0V
Ground - Distributor B	10-20mV	4.5-5.0V
Ground - Distributor C	0.5-1.5V	0.7-2.7V
Ground - Distributor D	0.2-0.3V	1.0-3.0V






X2, X3 CONNECTOR
(I.P WIRING HARNESS REFERENCE)

3) INJECTION NOZZLE, ECM POWER, ECM GROUND WIRING(IEFI-6)



K1 ECM
Y3 INJECTOR





- F1 Fuse Number 1

This is a fuse which always feeds "B+" power to ECM.
If you are to delete a fault code memorized on the ECM. Do as follows:

- Set Ignition Switch to "OFF" position
- Disconnect Fuse and wait for about 10 seconds
- Connect Fuse again
- Y3 Injection Valve(Injector)
 - Resistance Valve: 1-2ohms
 - Fuel Pressure: 0.75 bar
- K1 ECM Ground
 - ECM ground is at the terminal of ECM such as D1, C12 and B10.
 - Three ground terminals are at one location which is on the cylinder head.






4) COOLANT TEMPERATURE SENSOR(CTS), MANIFOLD AIR PRESSURE(MAP) SENSOR, VEHICLE SPEED SENSOR, THROTTLE POSITION SENSOR(TPS) IAC VALVE, O₂ SENSOR WIRING(IEFI-6)

- K1 ECM
 M2 IDLE AIR CONTROL VALVE(IAC VALVE)
 P1 VEHICLE SPEED SENSOR(VSS)
 P2 COOLANT TEMPERATURE SENSOR(CTS)
 P3 INTAKE MANIFOLD-AIR PRESSURE SENSOR(MAP)
 X3 OCTANE SELECTOR CONNECTOR
 P4 THROTTLE POSITION SENSOR(TPS)

30 _____
 15 _____
 15A _____



- P5 O₂ SENSOR (UNLEADED TYPE)
 P5-1 O₂ SENSOR (1.5 DOHC LEADED TYPE)
 P5-2 CO POTENTIO METER(1.5 MPFI LEADED TYPE)
 P6 MANIFOLD AIR TEMPERATURE SENSOR(MAT)

- Fault Code

Stored fault code	Information sensor	Cause of fault
13	Oxygen sensor	No voltage change
14	Coolant temperature sensor	Voltage too high or low
21	Throttle position sensor	Voltage too high or low
23	Manifold air temperature sensor	Voltage too high or low
24	Vehicle speed sensor	No speed impulses
32	EGR failure	Voltage too high or low
33	Manifold absolute pressure(MAP) sensor	No electr. spark advance
42	Electrical spark advance	Air/fuel mixture too lean
44	Oxygen sensor	Air/fuel mixture too rich
45	Oxygen sensor	ECM/EPROM fault
51	ECM	
53	Immobilizer failure	
54	Co adjust error	

- How to check a fault code

- If the "Service Engine Soon" indicator lights up while driving the engine, a fault has occurred to electronic control system.
- Trouble code can be obtained by flashing the 'Service Engine Soon' light if jumping ALDL terminal "B" to 'A'(using ALDL key) with the ignition 'ON'.
- To erase the trouble code, disconnect fuse #1 for 10 seconds with ignition switch "OFF".

- P2 Coolant Temperature Sensor(CTS)

Temperature(°C)	Resistance(kilo-ohms)
100	0.185
70	0.45
20	3.4
-4	7.5
-40	100

- P3 Intake manifold Air Pressure(MAP)

Pressure(bar)	MAP signal voltage(v)	Remarks
-0.2	3.7±0.2	Measuring at the Ter A and Ter B of MAP
-0.4	2.5±0.2	Measuring at the Ter A and Ter B of MAP
-0.6	1.5±0.2	Measuring at the Ter A and Ter B of MAP
-0.8	0.5±0.2	Measuring at the Ter A and Ter B of MAP

- P4 Throttle Position Sensor(TPS)

Throttle valve opening(%)	Resistance (kilo-ohms)	Signal Voltage(V)	Remarks
0	2±1	0.5±0.2	Measuring between the TPS Ter B and C
50	3.5±1	2.5±0.2	
100	6.5±1	4.5±0.2	


- P5 O₂ Sensor





- Voltage is changed between 0.1 and 0.9V
- M2 Idle Air Control Valve(IAC Valve)
- Idle RPM speed: 800-850 RPM

Resistance(ohms)	Remarks
20-100	Measuring between IAC Valve TER A and D
20-100	Measuring between IAC Valve TER B and C

- P1 VSS

- VSS utilized hole sensor theory:
- VSS signal is detected below 0.5V when VSS transistor is operated.
- VSS signal is detected about 12V when the transistor is not operated.










5) "SERVICE ENGINE SOON" LIGHT, FUEL PUMP, ALDL TESTER WIRING(IEFI-6)

K1 ECM
 M3 FUEL PUMP MOTOR
 S3 P/N SWITCH
 S4 OIL PRESSURE SWITCH

X1 ALDL CONNECTOR
 X2 FUEL PUMP TEST CONNECTOR
 K2 FUEL PUMP RELAY






AUTO TRANSMISSION VEHICLE

20								12
11								1

X5 CONNECTOR


6) IGNITION WIRING(IEFI-S)

K1 ECM
 L1 IGNITION COIL
 Y1 IGNITION MODULE
 Y2 DISTRIBUTOR




- L1 Ignition Coil
 - Insulation Resistance: ∞
 - 1st Resistance: 0.35-0.45ohms
 - 2nd Resistance: 7.5-9.5kilo-ohms
- Y1 Ignition Module
 - Pick up Coil
 - Insulation Resistance: ∞
 - Coil Resistance: 500-1500ohms
 - Ignition System Check

Measuring terminal	Cranking	Starting
Ground - Distributor A	0V	0V
Ground - Distributor B	10-20mV	4.5-5.0V
Ground - Distributor C	0.5-1.5V	0.7-2.7V
Ground - Distributor D	0.2-0.3V	1.0-3.0V







ECM CONNECTOR



IGNITION COIL




DISTRIBUTOR



X2, X3 CONNECTOR
(I.P WIRING HARNESS REFERENCE)

7) INJECTION NOZZLE, ECM POWER, ECM GROUND WIRING(IEFI-S)


K1 ECM
Y3 INJECTOR




- F1 Fuse Number 1

This is a fuse which always feeds "B+" power to ECM.
If you are to delete a fault code memorized on the ECM. Do as follows:


- Set Ignition Switch to "OFF" position
- Disconnect Fuse1 and wait for about 10 seconds
- Connect Fuse again
- Y3 Injection Valve(Injector)
 - Resistance Valve: 1-2ohms
 - Fuel Pressure: 0.75 bar
- K1 ECM Ground
 - ECM ground is at the terminal of ECM such as A12, D1 and D6.
 - Three ground terminals are at one location which is on the cylinder head.






ECM CONNECTOR



INJECTION VALVE



X9 CONNECTOR



8) COOLANT TEMPERATURE SENSOR(CTS), MANIFOLD AIR PRESSURE(MAP) SENSOR, VEHICLE SPEED SENSOR, THROTTLE POSITION SENSOR(TPS) IAC VALVE, O₂ SENSOR WIRING(IEFI-S)

- K1 ECM
 M2 IDLE AIR CONTROL VALVE(IAC VALVE)
 P1 VEHICLE SPEED SENSOR(VSS)
 P2 COOLANT TEMPERATURE SENSOR(CTS)
 P3 INTAKE MANIFOLD AIR PRESSURE SENSOR(MAP)

- P4 THROTTLE POSITION SENSOR(TPS)
 P5 O₂ SENSOR(UN LEADED TYPE)
 P5-1 O₂ SENSOR(LEADED TYPE)
 P6 MANIFOLD AIR TEMPERATURE SENSOR(MAT)

- Fault Code

Stored fault code	Information sensor	Cause of fault
13	Oxygen sensor	No voltage change
14	Coolant temperature sensor	Voltage too high or low
21	Throttle position sensor	Voltage too high or low
23	Manifold air temperature sensor	Voltage too high or low
24	Vehicle speed sensor	No speed impulses
33	Manifold absolute pressure(MAP) sensor	Voltage too high or low
42	Electrical spark advance	No elect. spark advance
44	Oxygen sensor	Air/fuel mixture too lean
45	Oxygen sensor	Air/fuel mixture too rich
51	ECM	ECM/EPROM fault

- How to check a fault code

- If the "Service Engine Soon" indicator lights up while driving the engine, a fault has occurred to electronic control system.
- Trouble code can be obtained by flashing the "Service Engine Soon" light if jumping ALDL terminal "B" to "A" (using ALDL key) with the ignition "ON".
- To erase the trouble code, disconnect fuse #1 for 10 seconds with ignition switch "OFF".

- P2 Coolant Temperature Sensor(CTS)

Temperature(°C)	Resistance(kilo-ohms)
100	0.185
70	0.45
20	3.4
4	7.5
-40	100

- P3 Intake manifold Air Pressure Sensor(MAP)

Pressure(bar)	MAP signal voltage(v)	Remarks
-0.2	3.7±0.2	Measuring at the Ter A and Ter B of MAP
-0.4	2.5±0.2	Measuring at the Ter A and Ter B of MAP
-0.6	1.5±0.2	Measuring at the Ter A and Ter B of MAP
-0.8	0.5±0.2	Measuring at the Ter A and Ter B of MAP

- P4 Throttle Position Sensor(TPS)

Throttle valve opening(%)	Resistance (kilo-ohms)	Signal Voltage(V)	Remarks
0	2±1	0.5±0.2	Measuring between the TPS Ter B and C
50	3.5±1	2.5±0.2	
100	6.5±1	4.5±0.2	



- P5 O₂ Sensor





- Voltage is changed between 0.1 and 0.9V
- M2 Idle Air Control Valve(IAC Valve)
- Idle RPM speed: 800-850 RPM

Resistance(ohms)	Remarks
20-100	Measuring between IAC Valve TER A and D
20-100	Measuring between IAC Valve TER B and C

- P1 VSS

- VSS utilized hole sensor theory:
- VSS signal is detected below 0.5V when VSS transistor is operated.
- VSS signal is detected about 12V when the transistor is not operated.










9) "SERVICE ENGINE SOON" LIGHT, TCC, FUEL PUMP, ALDL TESTER WIRING(IEFI-S)





K1 ECM
 K2 FUEL PUMP RELAY
 M3 FUEL PUMP MOTOR
 S3 BRAKE SWITCH
 S4 OIL PRESSURE SWITCH
 S2 P/N SWITCH

X1 ALDL CONNECTOR
 X2 FUEL PUMP TEST CONNECTOR
 Y4 TCC SOLENOID VALVE
 (AUTO T/M 3-SPEED)



FUEL PUMP

T.C.C SOLENOID
VALVE



AUTO TRANSMISSION VEHICLE


20							12
11							1

X5 CONNECTOR

10) LIGHT WIRING

E1 HEAD LAMP HIGH BEAM(LEFT)
E2 HEAD LAMP LOW BEAM(LEFT)
E3 HEAD LAMP HIGH BEAM(RIGHT)
E4 HEAD LAMP LOW BEAM(RIGHT)
K3 ILLUMINATION RELAY
K4 HEAD LAMP RELAY

M4 HLLD MOTOR(LEFT)
M5 HLLD MOTOR(RIGHT)
R2 HEAD LAMP LEVELING DEVICE(HLLD) CONTROL UNIT
S5 LIGHT SWITCH
S6 DIMMER SWITCH



- F2 58 Line

After a light switch is set to 1st or 2nd step, a illumination relay is operating to feed power to Fuse 2.

The line connect to F2 is called a 58 Line. The 58 Line feeds power to various illumination lamps and clearance lamps, etc.


- S5 Switch, S6 Dimmer Switch

A light Switch and A dimmer switch are display respectively on the wiring diagram.

But these are assembled physically in a device.


- [525] Alalog, Instrument panel.

This is connected to I/P Head Lamp high beam Indicator.




LIGHT SWITCH




DIMMER SWITCH



HEAD LAMP RELAY

HEAD LAMP(LR)



X2, X3 CONNECTOR
(I.P. WIRING HARNESS REFERENCE)




11) FRONT FOG LAMP & REAR FOG LAMP



E5 FRONT FOG LAMP(LEFT)
 E6 FRONT FOG LAMP(RIGHT)
 E7 REAR FOG LAMP(LEFT)
 E8 REAR FOG LAMP(RIGHT)
 K5 FRONT FOG LAMP RELAY

S7 FRONT FOG LAMP SWITCH
 S8 REAR FOG LAMP SWITCH
 S8-1 REAR FOG LAMP SWITCH (REAR FOG LAMP TYPE ONLY)
 E7-1 REAR FOG LAMP (LEFT) (REAR FOG LAMP TYPE ONLY)
 E8-1 REAR FOG LAMP (RIGHT) (REAR FOG LAMP TYPE ONLY)



FRONT FOG S/W





X2, X3 CONNECTOR
(I.P WIRING HARNESS REFERENCE)





12) DAY TIME RUNNING LIGHT, CLEARANCE LAMP, LICENCE PLATE LAMP, HORN WIRING

E9 A/T SELECTOR LEVER ILLUMINATION LAMP
 E10 POSITION LAMP(LEFT)
 E11 POSITION LAMP(RIGHT)
 E12 CLEARANCE LAMP(LEFT)
 E13 LICENCE PLATE LAMP
 H1 HORN

E14 LICENCE PLATE LAMP
 E15 CLEARANCE LAMP(RIGHT)
 K6 DAY TIME RUNNING LIGHT(DRL) RELAY
 K7 DRL CONTROL UNIT
 S9 HORN SWITCH
 K25 HORN RELAY






13) GLOVE BOX LAMP, CIGARETTE LIGHTER, DIGITAL CLOCK ROOM LAMP, TRUNK ROOM LAMP, WIRING


E16 ILLUMINATION LAMP – CIGARETTE LIGHTER
 E17 ILLUMINATION LAMP – ASH TRAY
 E18 TRUNK ROOM LAMP
 E18-1 TRUNK ROOM LAMP(5-DOOR)
 E19 ROOM LAMP
 E49 GLOVE BOX ILLUMINATION LAMP
 H2 DIGITAL CLOCK

R3 CIGARETTE LIGHTER
 S10 GLOVE BOX ILLUMINATION SWITCH
 S11 TRUNK ROOM LAMP SWITCH(5-DOOR)
 S12 DOOR CONTACT SWITCH-R.R
 S13 DOOR CONTACT SWITCH-R.L
 S14 DOOR CONTACT SWITCH-F.R
 S15 DOOR CONTACT SWITCH-F.L




- H2 Digital Clock

- The power operating a clock is H2 digital clock terminal 3 supplied B+ and H2 digital clock terminal 4 connected to ground line.
- H2 digital clock terminal 1 is feeded from 15 line through fuse 13. The 15 line is connected to an illumination lamp when an ignition switch is "ON".
- H2 digital clock terminal 2 is feeded from 58 line and this is a circuit for controlling brightness of an illumination lamp when light switch is on the first step.
- How to adjust a digital clock
 - "H" hour adjusting(an ignition switch is "ON") adjust hour by pushing the "H" button. It is adjusted fastly pushing continuously but done by one hour at one time.
 - "M" minute adjusting(an ignition switch is "ON") adjust minute by pushing the "M" button. On pushing continuously be adjusted fastly but on pushing onetime, be done by one minute.
 - "S" minute setting
On pushing this button, minute become zero.
 - "DISP" display button
When an ignition switch is "OFF" position, time is displayed in case of pushing this button.



CIGARETTE LIGHTER CLOCK

ROOM LAMP





ASH TRAY
ILLUMINATION LAMP

CLOCK
CONNECTOR


X5A CONNECTOR

X12 CONNECTOR


REAR FOG SW



DIGITAL CLOCK



GLOVE BOX SWITCH




14) BRAKE LAMP, REVERSE LAMP, TCC WIRING


E20 BRAKE LAMP(LEFT)
 E20-1 CENTER HIGH MOUNTING
 BRAKE LAMP(3-DOOR,5-DOOR)
 E21 BRAKE LAMP(RIGHT)
 E22 REVERSE LAMP(LEFT)

E23 REVERSE LAMP(RIGHT)
 S2 P/N SWITCH(3AT)
 S2-1 P/N SWITCH(4AT)
 S16 BRAKE SWITCH(M/T)


S17 BRAKE SWITCH(3AT)
 S18 REVERSE LAMP SWITCH(MT)
 X1 ALDL CONNECTOR
 Y4 TCC SOLENOID VALVE




BRAKE LAMP REVERSE LAMP




ALDL CONNECTOR




BRAKE SWITCH CONNECTOR



T.C.C SOLENOID VALVE








X3 CONNECTOR



X4A CONNECTOR

- S2 P/N Switch(A/T)
"D" and "E" Terminal of P/N Switch is "ON" when Selector Switch is at the R position.
- S17 Brake Switch(A/T)
A brake Switch for A/T has four terminals. A and B terminals are always "on" and then "off" on braking the pedal.
Because this is connected to TCC Controller.
TCC is released on braking.
C and D terminals are "ON" during being braked.
- S16 Brake Switch(M/T)
A break switch for M/T has two terminals. When braking a cross point of A and B is "ON" and Brake system Warning Light is ON.
- S18 Reverse Lamp Switch(MT)
A Reverse Switch – installed on the trans axle – has two cross points.
A cross point is "ON" only when a shift lever is at R position.
- K1 ECM Ter A2(3A/T)
ECM actuates Torque Converter Clutch Solenoid valve under the TCC operating Condition.
 - TCC operating condition is as follows:
 - 1) Brake pedal is off.
 - 2) When Oil pressure switch is closed to operate 3 step gear.
 - 3) When the throttle valve opening percentage is constant.
 - 4) When coolant temperature is over about 70°C.
 - 5) When vehicle speed is over 41km/h.
 - Reference
ECM Terminal A2 is used for controlling TCC in case of A/T, and for controlling a shift-up indicator in case of M/T respectively.



AUTO TRANSMISSION VEHICLE

1				4
5				9
10				14

X8 CONNECTOR

20									12
11									1

X5 CONNECTOR

15) TURN SIGNAL LAMP, HAZARD LAMP WIRING

E24 ILLUMINATION LAMP - HAZARD LAMP SWITCH

E25 ADDITIONAL TURN SIGNAL LAMP(LEFT)

E26 TURN SIGNAL LAMP-R.L

E27 TURN SIGNAL LAMP-F.L

E28 TURN SIGNAL LAMP-F.R


E29 TURN SIGNAL LAMP-R.R

E30 ADDITIONAL TURN SIGNAL LAMP-RIGHT

K8 TURN SIGNAL LAMP RELAY

S19 HAZARD LAMP SWITCH

S20 TURN SIGNAL LAMP SWITCH



- E24 Illumination Lamp-Hazard Lamp Switch
This lamp has two functions.

- Only Illumination Lamp function at the 1 step of the switch.
- When Hazard Lamp Switch is "ON". It is on and off to notice that Hazard lamp is operating.


- S19 Hazard Lamp Switch
Each Hazard Lamp and Turn Signal Lamp have a fuse.

- S20 Turn Signal Lamp Switch
Turn Signal Lamp Switch is drawn individually on the wiring diagram but physically assembled within one body.


- K8 Turn Signal Lamp Relay
This relay receive power through Hazard lamp switch and supply current periodically. The current feed Hazard lamp Terminal 49a and Turn Signal Lamp Terminal 49a via Turn Signal lamp relay Terminal 49a.

So that Each Turn signal Lamp is on and off.


- [533], [539] analog I/P
This is connected to a turn signal lamp left and right.




HAZARD LIGHT SWITCH




TURN SIGNAL LAMP(R)









TURN SIGNAL LAMP(R)



BLINICER UNIT




X5 CONNECTOR




16) CHIME BELL, AUTO TRUNK, FUEL INLET SWITCH WIRING

K9 CHIME BELL
 S21 AUTO TRUNK SWITCH
 S22 FUEL INLET SWITCH
 S37 SEAT BELT SWITCH


Y5 AUTO TRUNK SOLENOID
 Y5-1 AUTO TRUNK SOLENOID(3-DOOR,5-DOOR)
 Y6 FUEL INLET SOLENOID




- S37 seat belt switch
 This switch is "OFF", when fixing a seat belt.
- 537 Analog I/P
 - This is connected to a seat belt warming lamp in I/P.






CHIME - WARING
RELAY CONNECTOR




X5 CONNECTOR



X8 CONNECTOR




AUTO TRUNK SWITCH



17) REAR WINDOW DEFROSTER WIRING


E31 ILLUMINATION – REAR WINDOW DEFROSTER SWITCH
 E32 OPERATION INDICATION-REAR WINDOW DEFROSTER SWITCH

K10 REAR WINDOW DEFROSTER TIME RELAY
 R11 REAR WINDOW DEFROSTER
 S23 REAR WINDOW DEFROSTER SWITCH




REAR WINDOW DEFROSTER




REAR WINDOW DEFROSTER TIME RELAY CONNECTOR



X5 CONNECTOR




X8 CONNECTOR







18) WIPER WIRING





K11 FRONT WIPER RELAY
 K12 WASHER PUMP RELAY(3-DOOR,5-DOOR)
 K13 REAR WIPER RELAY(3-DOOR,5-DOOR)
 M6 WASHER PUMP
 M7 WIPER MOTOR
 M8 WASHER MOTOR(3-DOOR,5-DOOR)

M9 REAR WIPER MOTOR(3-DOOR,5-DOOR)
 M10 AUTO ANTENNA
 R4 WIPER INTERVAL CONTROL SWITCH
 S24 WASHER SWITCH
 S25 WIPER SWITCH
 S25-1 REAR WIPER SWITCH(3-DOOR,5-DOOR)



- **S24 Wiper Switch**
 A wiper switch has two functions as follows;
 - OFF, INT, LO, HI function.
 - Operating a washer fluid pump motor terminal numbers indexed on the switch.
- **K11 Wiper Relay**
 A wiper relay has two major functions.
 - When a switch is at the INT position, this wiper relay operates periodically with 4 to 21 seconds interval according to manipulate the interval control switch.
 - When operating a washer fluid switch, a washer fluid pump motor operates and power is supplied to terminal 53C of K11 wiper relay. A wiper relay operates for about 4 seconds from the moment when a washer fluid switch is OFF.
- **S25 wiper switch, s25-1 rear wiper switch**
 A wiper switch and A rear wiper switch are display respectively on the wiring diagram.
 But these are assembled physically in a device






19) CASSETTE RADIO WIRING

H3 SPEAKER-F.L
 H4 SPEAKER-R.L
 H5 SPEAKER-F.R

H6 SPEAKER-R.R
 H7 CASSETTE RADIO




- M16 Auto Antenna



- When a radio is "ON":
12V power is supplied to terminal 3 of cassette radio and the inner relay of an auto antenna operates.

Because the cross of C is connected to "+" and the cross of D is connected to "-", the antenna motor circulates.

When an antenna reaches at the end position, the cross of "A" is connected and the cross of "B" is disconnected. At this time, the antenna motor stops and keeps the current status on.

- When a radio is "OFF":
The inner relay does not operate because power is not feeded from terminal 3 of H6 radio. At this time, the cross of C is connected to "-", and the cross of A is connected to "+" so that the antenna motor operates and the antenna is down.
When the antenna arrives at the bottom, the cross of A is disconnected, and the cross of B is connected to so that the antenna motor stops.






20) POWER WINDOW WIRING(LHD, RHD)


M10 POWER WINDOW MOTOR(F.L)-LHD
 M12 POWER WINDOW MOTOR(F.R)-LHD
 M13 POWER WINDOW MOTOR(R.L)-LHD
 M14 POWER WINDOW MOTOR(R.R)-LHD
 M15 POWER WINDOW MOTOR(F.R)-RHD
 M16 POWER WINDOW MOTOR(F.L)-RHD
 M17 POWER WINDOW MOTOR(R.R)-RHD
 M18 POWER WINDOW MOTOR(R.L)-RHD

S26 POWER WINDOW MAIN SWITCH-LHD
 S26-1 POWER WINDOW MAIN SWITCH-RHD
 S37 POWER WINDOW SWITCH(F.R)-LHD
 S38 POWER WINDOW SWITCH(R.L)-LHD
 S39 POWER WINDOW SWITCH(R.R)-LHD
 S40 POWER WINDOW SWITCH(F.L)-RHD
 S41 POWER WINDOW SWITCH(F.R)-RHD
 S42 POWER WINDOW SWITCH(R.L)-RHD




POWER WINDOW - LHD

POWER WINDOW - RHD




POWER WINDOW SWITCH




POWER WINDOW MAIN SWITCH



X63, 64 CONNECTOR





X61, 62 CONNECTOR



X6 CONNECTOR

- Whenever the power window main switch(S26, S26-1) is not operated, all contact points is connected to the ground.
If the power window S/W of the front driver seat is down, the terminal 8 is connected to B+(C) and 9 is not operated so that the ground terminal.
- The main power is ON/OFF by the rear power window lock S/W so that it is impossible to operate the power windows individually at the co-driver seat or the rear seats.
(For example: when a children is in the car, the main S/W is OFF so that the rear power window S/W is not operated.)



21) CENTRAL DOOR LOCKING SYSTEM WIRING (LHD, RHD)

K14 CENTRAL DOOR LOCKING RELAY

K14-1 CENTRAL DOOR LOCKING RELAY(RHD)

M19 ACTUATOR, FRONT RIGHT-LHD

M20 ACTUATOR, REAR RIGHT-LHD

M21 ACTUATOR, REAR LEFT-LHD


M22 ACTUATOR, FRONT LEFT-RHD

M23 ACTUATOR, REAR RIGHT-RHD

M24 ACTUATOR, REAR LEFT-RHD


S27 CENTRAL DOOR LOCKING SWITCH-LHD

S27-1 CENTRAL DOOR LOCKING SWITCH-RHD



CENTRAL DOOR LOCKING - LHD


CENTRAL DOOR LOCKING - RHD



X61, 62 CONNECTOR



X63, 64 CONNECTOR



X5 CONNECTOR

CENTRAL DOOR
LOCKING SWITCH
CONNECTORACTUATOR
CONNECTOR

- K14, K14-1 central door locking relay

A central door locking relay operates for 0.7 second when opening or locking.

- No Operating:

When the relay is not operating, the terminal 1 and terminal 7 are connected to terminal 4 in the relay.

- When Locking:



When S27, S27-1 central door locking switch is set to the locking position, terminal 7 is connected to the ground and "A" relay in the relay is operating for 0.7 second.

At this time, terminal is "+" and terminal 2 is "-" so that three actuators operates contemporary to the locking direction.

- On Opening:

When S27, S27-1 is set to the opening position, terminal 6 is connected to the ground and the inner "B" relay of the relay is operating for 0.7 second.


The terminal 1 is "-" and the terminal 2 is "+" so that three actuators operates contemporary to the opening direction.







22) I-P WIRING

E33 POWER WARNING LAMP
 E34 AIR BAG WARNING LAMP
 E35 ABS WARNING LAMP
 E36 FUEL WARNING LAMP
 E37 OIL WARNING LAMP
 E38 "SES" INDICATOR
 E39 PARKING BRAKE FLUID WARNING LAMP
 E40 HIGH BEAM INDICATOR

E41 CHARGING WARNING LAMP
 E42 WASHER FLUID WARNING LAMP
 E43 TURN SIGNAL LAMP - LH
 E44 DOOR OPEN WARNING LAMP
 E45 SEAT BELT WARNING LAMP
 E46 TURN SIGNAL - RH
 E47 I-P ILLUMINATION LAMP
 H8 I-P




INSTRUMENT PANEL



LAMP	H9 FUEL LEVEL GAUGE
IING LAMP	H10 TEMPERATURE GAUGE
LH	H11 SPEEDO METER
3 LAMP	H12 TACHO METER
LAMP	R5 FUEL TANK UNIT
P	R6 COOLANT TEMPERATURE UNIT
	R7 WASHER FLUID LEVER SWITCH
	S43 NSBU SWITCH(4 AT)

S28 BRAKE FLUID LEVEL SWITCH
S29 PARKING BRAKE SWITCH
R11 OVER SPEED WARNING SWITCH

_____ 30
_____ 15
_____ 15A
_____ 58



- E38 "Engine Service Soon" indicator
An "Engine Service Soon" indicator is ON when an ignition switch is "ON" or ECM has any trouble.(K1 ECM controls terminal) to be connected to a ground and when terminal A and B of ALDL connector is jumped with wire and an ignition switch is "ON" an engine control indicator is ON and OFF to indicate a fault code.

- R5 Fuel Sensor
A fuel level sensor and a fuel warning lamp switch is installed in the fuel tank and these are assembled in a housing.

- Fuel level sensor resistance
1/4 degree of fuel level: 148~192ohms
1/2 degree of fuel level: 97~127ohms
3/4 degree of fuel level: 66~86ohms
- Fuel warning lamp
After a fuel warning lamp is "ON", a driver can drive up to about 50km.

- R6 Temperature Sensor

Resistance
50°C: 226-340ohms
70°C: 123-185ohms
80°C: 92-138ohms
100°C: 53-80ohms
110°C: 42-62ohms
120°C: 32-82ohms

- 20 ALT(Alternator) L Terminal

When an ignition switch is ON, the current is supplied as below and a battery charging warning lamp is ON:
F13 → Battery charging warning lamp → ALT L Terminal

→ Rotary coil Ground.

- 28 Ignition Coil "-"

An Ignition Coil "-" Terminal detects engine RPM

- 148 F4 High Beam Lamp


A Fuse 4 is connected to a high beam lamp(right)

- 300 L

Turn signal lamp left

- 312 R



Turn signal lamp right



X11B CONNECTOR

X4 CONNECTOR

X11A CONNECTOR





23) ABS(OPTION)



K15 ABS WARNING LAMP MODULE
 K16 ABS RELAY
 K17 ABS - ECM(EBCM)
 M25 ABS MOTOR(F.L)
 M26 ABS MOTOR(F.R)
 M27 ABS MOTOR(R.R)

P7 WHEEL SPEED SENSOR(F.L)
 P8 WHEEL SPEED SENSOR(F.R)
 P9 WHEEL SPEED SENSOR(R.L)
 P10 WHEEL SPEED SENSOR(R.R)
 S28 BRAKE FLUID LEVEL SWITCH
 S29 PARKING BRAKE SWITCH

Y7 SOLENOID(F.R)
 Y8 SOLENOID(F.L)





X7 CONNECTOR

ABS-ECU POWER END GROUND
(ABS HARNESS REF.)ABS-ECU
(ABS HARNESS REF.)

24) TCM(OPTION)

K18 TRANSMISSION CONTROL MODULE(TCM)

P1 VEHICLE SPEED SENSOR(VSS)



X41 CONNECTOR(4-SP A/T)

X42 CONNECTOR(4-SP A/T)

X43 CONNECTOR(4-SP A/T)

A	1									12
B	1									12



C	1									16
D	1									16

TCM CONNECTOR(4-SP A/T)

25) IMMOBILIZER, AIR BAG(OPTION)

K19 IMMOBILIZER CONTROL UNIT
 K20 AIR BAG CONTROL UNIT

R8 TRANSPONDER DETECTION COIL
 R9 CONTACT COIL
 S9-1 HORN SWITCH(AIR BAG TYPE)




26) AIR-CONDITIONING WIRING, ELECTRIC FAN, BLOWER MOTOR WIRING(IEFI-6 TYPE)


E48 ILLUMINATION LAMP - A/C CONTROL SWITCH
 K21 ELECTRIC FAN RELAY - HIGH SPEED
 K22 ELECTRIC FAN RELAY - LOW SPEED
 K23 A/C COMPRESSOR RELAY
 K24 BLOWER MOTOR RELAY
 M25 ELECTRIC MOTOR - AUX

M26 ELECTRIC MOTOR
 M27 BLOWER MOTOR
 R10 BLOWER MOTOR RESISTER
 R11 ELECTRIC FAN LOW SPEED RESISTER
 S32 FAN CYCLING SWITCH
 S33 RADIATOR TEMPERATURE SWITCH

S34 LOW PRESS.
 S35 HIGH PRES.
 S36 A/C CONTR.
 V1 DIODE
 Y1 A/C COMPR.
 Y10 FRESH AIR



A/C (IEFI-6 TYPE)



TYPE)




S34 LOW PRESSURE CUT-OFF SWITCH
 S35 HIGH PRESSURE CUT-OFF SWITCH

SISTER S36 A/C CONTROL SWITCH


V1 DIODE

TCH Y1 A/C COMPRESSOR


Y10 FRESH AIR CONTROL MODE SOLENOID

**FI-6 TYPE)**

AIRCON CONTROL SWITCH



X2 CONNECTOR



X4 CONNECTOR

- S34 Low Pressure Shield Switch

This is installed on the air-con low pressure line and the switch is "OFF" in case that the pressure is below $1.6 \pm 0.5 \text{ kg/cm}^2$.

- S35 High Pressure Shield Switch

This is installed at the rear side of an air-con compressor (on the high pressure line) and the switch is "OFF" in case that the pressure is over 29 kg/cm^2 .

- V1 Diode

This prohibit the instant re-operation from reverse power when an air-con compressor is "OFF".

- 87 ECM Ter B8

When an air-con rotary switch is operated, ECM detects an air-con operating signal.

- 85 ECM Ter A4

When an air-con operating signal is detected from Terminal A4 and an air-con is not over load, the terminal A4 of ECM is connected to ground so that K23 air-con compressor relay is operated.

- 89 ECM Ter C9

The fan cycling switch (violet) is installed on the high pressure line at the rear side of an air-con compressor and the switch is "ON" when the pressure is over 18.21 kg/cm^2 . At this time, the terminal C9 of ECM detects the fan cycling switch operating signal.

When ECM receive the operating signal of the fan cycling switch, under the control of ECM the terminal B4 of ECM is connected to ground so that the K21 electric fan high speed relay is operated.


- Notice

An electric fan high speed relay operate under the condition as below:


- 1) Coolant temperature is over 106°C .
- 2) When the operating signal of the fan cycling switch is detected by ECM.
- 3) When the fault code 14 of the temperature sensor is input.
- 4) When the terminal A and B of ALDL connector is jumpered.

- S33 Temperature Switch


When the coolant temperature is over 90°C , this switch is operated so that the cooling fan is operated when the temperature is 85°C , the switch is disconnected and the cooling fan is off.




TEMPERATURE SWITCH



Pressing air conditioning switch A/C once makes air conditioning system ON and lightens the indication lamp.
Pressing the switch twice makes A/C system OFF and turn off the lamp.




- Air flow can be directed towards the center and sides of the vehicle.
- Air flow can be directed towards the floor area of the front seat, center, and side window.
- Air flow can be directed towards the floor area of the front seat.
- Defrosting of front and side windows can be possible.



FAN SWITCH



The fan switch provides speed control of the blower fan(4 fan speeds).



FRESH AIR CONTROL LEVER



↑ Circulate the air inside the vehicle.




AIRCON COMPRESSOR,
ELECTRIC FAN RELAY LOW
SPEED (MICRO RELAY)



ELECTRIC RELAY
HIGH SPEED



BLOWER SWITCH

BLOWER
RESISTORFAN CYCLING
SWITCH


ELECTRIC FAN

26-1) AIR-CONDITIONING WIRING, ELECTRIC FAN, BLOWER MOTOR WIRING(IEFI-S TYPE)


E48 ILLUMINATION LAMP - A/C CONTROL SWITCH
 K21 ELECTRIC FAN RELAY - HIGH SPEED
 K22 ELECTRIC FAN RELAY - LOW SPEED
 K23 A/C COMPRESSOR RELAY
 K24 BLOWER MOTOR RELAY
 M25 ELECTRIC MOTOR - AUX

M26 ELECTRIC MOTOR
 M27 BLOWER MOTOR
 R10 BLOWER MOTOR RESISTER
 R11 ELECTRIC FAN LOW SPEED RESISTER
 S32 FAN CYCLING SWITCH
 S33 RADIATOR TEMPERATURE SWITCH

S34 LOW PR
 S35 HIGH PR
 S36 A/C CON
 V1 DIODE
 Y1 A/C COM
 Y10 FRESH A




A/C (IEFI-S TYPE)




I TYPE)

S34 LOW PRESSURE CUT-OFF SWITCH
 S35 HIGH PRESSURE CUT-OFF SWITCH
 S36 A/C CONTROL SWITCH
 V1 DIODE
 Y1 A/C COMPRESSOR
 Y10 FRESH AIR CONTROL MODE SOLENOID

ISTER
 CH



R-S TYPE)



27) HEAD LAMP LEVELING DEVICE(OPTION)

1. HLLD Actuating Motor


(1) Construction and working principle

Actuating motor works by electric power supplied by driver's operation of head lamp leveling device switch. Worm and worm gear change the rotating power of the actuating motor into linear movement which pushes and pulls the device shaft.


The shaft linked with the reflector, moves forward and backward.

Then the reflector of the head lamp can rotate up and down around the pivot.

The more the reflector turns downward the bigger the downward – inclination of dipped – beam, and vice versa. So, when driver rotates the switch to downward, the reflector of the lamp turns downward around the pivot. If the driver turns it to the opposite direction the reflector moves upward around the pivot.




1. AIMING POINT TO LEFT AND RIGHT
2. AIMING POINT TO UP AND DOWN
3. PIVOT
4. DEVICE SHAFT
5. ADJUSTING KNOB
6. ACTUATING MOTOR



(2) HLLD switch

- Position 0
One person on driver's seat .
Two persons on front seat.
(One driver and one co-driver)
- Position 1
All seats occupied
(5 persons in passenger compartment)
- Position 2
5 persons in passenger compartment plus weight(Max 160 kg) in loading compartment.
- Position 3
One person on driver's seat plus weight(Max 350 kg) in loading compartment.



2. Test Method

R2 HLLD CONTROL SWITCH
 M4 HLLD MOTOR (LEFT)
 M5 HLLD MOTOR (RIGHT)

- 1) With ignition switch "ON", disconnect the HLLD switch connector.
- 2) Connect voltage meter between the HLLD switch connector, terminal "2" and the vehicle body ground, and measure the voltage.

Normal : 12V

If the voltage is abnormal, check the open of the wiring and fuse No. 6.

- 3) Measure the resistance between the HLLD switch terminal "4" and "2".

If the resistance is abnormal, exchange the HLLD switch.

Position 0	0.2ohm
Position 1	156.6ohms
Position 2	234ohms
Position 3	252ohms

